



FujiFilm FinePix S4500 Battery Replacement

Follow these steps to remove and replace batteries

Written By: Vicente Rios



INTRODUCTION

Out of juice? Follow these steps to replace the batteries in your camera.

Step 1 — Batteries



- Place camera with shutter button down

Step 2



- Pull the battery cover switch

Step 3



- Open battery cover to view the batteries

Step 4



- Remove batteries; make sure batteries are oriented correctly when replacing.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-16 09:45:20 AM.